

CT-7000 II" CABLE TENSIONER
CT-7000L II 1/2" CABLE TENSIONER

INSTALLATION PROCEDURE:

1. Remove nuts, springs and washers from assembly.
2. Reel off a minimum of 2 layers of cable from winch.
3. With mounting angles and tension plate assembled. Place on lip of winch housing directly behind and inside flange of winch spool. Then bolt assembly to lip and install washers, spring and nuts.
4. Adjust spring tension to desired pressure and reel in cable on winch. Put winch in free spool position to see if drum over-runs. The more pressure applied by the spring, the better.

